

Gasmet™ Portable Sampling Unit



GASMET Portable Sampling Unit

The Gasmet Portable Sampling Unit has been designed for portable emission monitoring measurements.

The Gasmet Portable Sampling Unit is used for on-site measurements. It can be used for measuring trace concentrations of pollutants in wet, corrosive gas streams. The sample gas can be measured undiluted and without drying since the sample pump, heated filter and valve are located in a module that is heated to 180 °C. From the Sampling Unit the gases can be directed into Gasmet FTIR gas analyzer.

The Gasmet Portable Sampling Unit includes power connections and temperature controllers for heated lines and heated module. The Gasmet Portable Sampling Unit is connected to an external PC through Gasmet FTIR Gas Analyzer and can be controlled by Calcmet software.

The function of the Portable Sampling Unit is automatic, but sample pump and valve can be controlled also manually.

In the case of a power failure or if the temperature (pump, lines, sample cell) is below setting, the automatic 3-way valve switches sample gas to zero gas to prevent condensation. Sample pump can not be switched on before all temperatures have reached the setting. In addition, the zero calibration of the Gasmet FTIR gas analyser can be done automatically with the Portable Sampling System.

As an option, the sampling unit can be equipped with a sample probe and / or heated lines. The maximum length for the heated line is 19m + 1m with 230 VAC and 9m + 1m with 115 VAC power supply. There is also an optional integrated O₂ – sensor that supplements the capabilities of the Gasmet FTIR gas analyzers.

GASMET-USA Tel: 512.331.0073 Fax: 512.331.5353 sales@Gasmet-USA.com www.Gasmet-USA.com

Gasmet Technologies Oy

Pullitie 8 A
FI-00880 Helsinki
Finland

TEL: +358 9 759 00 400
FAX: +358 9 759 00 450
EMAIL: contact@gasmet.fi

WEB: www.gasmet.fi
VAT NO: FI19526395

General parameters

Operating temperature: 20 ± 20°C, non condensing
Storage temperature: -20 - 60°C, non condensing
Power supply: Separate models for 100-115 and 230 V / 50 -60 Hz
Power consumption: 400 - 3600 W, depending of the sample lines (without sample probe)

Heated Sample Pump

Material: 316 SS
Diaphragms: Teflon
Maximum flow: ~4 l/min, constant
Temperature: 180 °C, max.

Heated Filter

Material: Bonded Microfibre or Sintered ss-316
Gas filtration: filtration of particulates 2µm
Temperature: 180 °C

Temperature Controllers

Material: Temperature range: 0 – 180 °C
Display: digital, 4 digits

Valves

Pressure: 0-2 bar
Temperature: 60 °C max.
Valves: Sample gas / zero gas

Gas Connectors

Sample Gas inlet: 1 pcs, 6 mm Swagelok
Sample Gas outlet: 1 pcs, 6 mm Swagelok
Zero Gas inlet: 1 pcs, 6 mm Swagelok

Electrical Connectors

Power connection: CEE7 standard European Schuko plug or fixed cable

Enclosure

Material: SS 316
Dimensions (mm): 400 × 300 × 210 mm
Weight: 12.3 kg
CE - Label: EMI guideline 89/336/EC

Optional Oxygen Sensor

The O2 – reading can be displayed on the Calcmet – software

Principle: ZrO₂ Cell
Measuring range: 0.1 – 25 %
Accuracy: <2% from FS
Calibration: Single point calibration with air

Optional Heated line

Tube size: 4 mm, inner diameter
Core material: Teflon core
Operating pressure: max. 400 kPa
Temperature: max. 200 °C
Fittings: 6 mm Swagelok
Power supply: 230 VAC or 115 VAC
Power density: 120 Watts /meter

The maximum length of the heated line is 19m + 1m (230 VAC) and 9m + 1m (115 VAC).

Optional Sample probe

Sample Probe: PSP4000H

- **Power density:** 320 Watts
- **Operating temperature:** 0 – 180 °C
- **Filter element:** ceramic 2µm
- **Dust loadings:** < 2 g/m³

Probe Tube Material: SS 316 Viton

- **Probe length:** 1 m
- **Sample temperature:** 600 °C max.
- **Sample pressure:** 1 bar max..

Other probes for high temperatures and for high dust loadings

GASMET-USA Tel: 512.331.0073 Fax: 512.331.5353 sales@Gasmeter-USA.com www.Gasmeter-USA.com